

Jaime 1000 range

RS232 Link
Parallel Link



A13862

IMAJE SA. reserves the right to alter the specifications and the design of this product at any time without giving prior notice.
Reproduction, in whole or in part, is not allowed.

IMAJE SA. Siège social : 9, rue Gaspard Monge B.P. 110 - 26501 BOURG-LES-VALENCE Cedex - France
☎ : 04 75 75 56 00 - 📠 : 04 75 82 98 10 - <http://www.imaje.com>
Edition Anglaise

Contents

A13862 Version E

Contents	1
General	2
General principle of a V24 exchange	3
List of the V24 commands	4
Protocol	5
Appendix	6
Parallel link Presentation	7
Parallel link Selection of messages	8

Read all these instructions

- FIRE:

CAUTION:

Consult the safety data sheet for the ink to determine whether your printer uses INFLAMMABLE inks and additives.

If this is the case:

- Place a foam, CO₂ or powder extinguisher close to the printer (maximum 10 metres).
- The printer must be kept in a well aired place away from sources of heat, flames or sparks.
- Never leave ink, additive or cleaning solution cans or cloths soaked in ink near the printer.
- Never smoke near the printer. Display a notice with "NO SMOKING, INFLAMMABLE INK" close to the printer.
- Make sure to keep the printer very clean, as a dry ink deposit is highly inflammable.
- The ink, additive and cleaning solution cans must be closed and stored in a well aired room.

- ELECTRICAL CONNECTION:

- The connection to the single phase electricity supply network must use a standard 3 pin plug with earth ; this plug must be easy to access.
- The earth connection must comply with applicable regulations.

- HEALTH:

- It is strictly forbidden to wear contact lenses when handling consumable products.
- It is recommended that ink-resistant gloves and safety goggles should be worn during filling and cleaning operations.

Disconnect the printer from the mains power supply before any intervention.

IMAJE cannot be in any way held responsible should the above-mentioned rules not be respected, and in general for the non-respect of elementary safety rules concerning the utilization of these machines.

All modifications without written authorization from imaje are prohibited and their possible consequences are the responsibility of the person who performed them.

The same applies for any use of the printer which does not comply with the printer's specifications.

REVISION

Update to instruction manual "RS232 link - parallel link for the Jaime 1000 range"

- The revision index A0 corresponds to the first edition of this manual.
- The revision index changes with every modifications.
The modified pages are mentioned in the following table. This one indicates all updating since the first edition.

Date of edition	Document revision index	JAIME 1000 Software index	Modified pages
July 1994	A0	D4	Initial edition
July 1995	B	D5	All
Marsh 1999	E	D7/A43	All

CONTENTS

1	FOREWORD. REVISION. CONTENTS	(5 pages)
---	------------------------------	-----------

2	GENERAL	(14 pages)
---	---------	------------

1	Introduction	2-2
2	Description of the signals used	2-3
3	Electrical specifications	2-4
4	Timing diagram	2-4
5	Material configuration	2-5
6	Software configuration	2-10
7	Memory aid	2-14

3	GENERAL PRINCIPLE OF A V24 EXCHANGE	(3 pages)
---	-------------------------------------	-----------

1	General principle of a V24 exchange	3-2
---	-------------------------------------	-----

4	LIST OF THE V24 COMMANDS	(4 pages)
---	--------------------------	-----------

1	Sendings	4-2
2	Requests	4-3
3	List of the V24 commands	4-4

CONTENTS

5 PROTOCOL (64 pages)

1	Sendings concerning the printer	5-3
2	Sending concerning the print heads	5-15
3	Sendings concerning messages	5-16
4	Sendings concerning the variable elements (counter, hour code, auto-dating)	5-26
5	Requests concerning the printer	5-31
6	Requests concerning the heads	5-44
7	Requests concerning the message	5-46
8	Requests concerning the variable elements	5-49
9	General message structures	5-52
10	Detail of the data bytes	5-53

6 APPENDIX (16 pages)



1	Examples of message programming	6-2
2	Commanding the printer by a programme in BASIC	6-9
	Performance	6-13
	Synoptic of a V24 exchange	6-15

CONTENTS

7	PARALLEL LINK - PRESENTATION	(6 pages)
1	Introduction	7-2
2	Characteristics of the Parallel link	7-3
3	Connection diagram	7-4
8	PARALLEL LINK - SELECTION OF MESSAGES	(11 pages)
1	Selection of a message from the library	8-2
2	Input signals diagram	8-4
3	Master jet, master message	8-6
4	General operation of the parallel interface	8-7
5	Restriction of the parallel interface operation	8-7
6	Usage according to printer configurations	8-8
7	Summary charts	8-11

Contents

1	Introduction	2-2
2	Description of the signals used	2-3
2.1	Reference (GND)	2-3
2.2	DSR (Data Set Ready) in voltage levels transmission or DSR+ and DSR- in loop transmission.	2-3
2.3	DTR (Data Terminal Ready) in voltage levels transmission	2-3
2.4	RTS (Request To Send)	2-3
2.5	CTS (Clear To Send)	2-3
2.6	TXD (Transmit Data) in voltage levels transmission or TTY OUT+ and TTY OUT- in loop transmission.	2-3
2.7	TXD (Receive Data) in voltage levels transmission or TTY IN+ and TTY IN- in loop transmission.	2-3
3	Electrical specifications	2-4
4	Timing diagram	2-4
5	Material configuration	2-5
5.1	Presentation of the terminal block of the Industrial Interface	2-5
5.2	Configuration of the jumpers on the Industrial Interface board	2-6
5.3	Presentation of the different modes	2-7
5.4	Suggested connection diagrams	2-7
5.4.1	Slave. Voltage transmission	2-7
5.4.2	Slave. Loop transmission	2-8
5.4.3	Complete dialogue. Transmission in voltage.	2-9
6	Software configuration	2-10
6.1	Transmission speed and format on Serie 4	2-10
6.1.1	Programming	2-10
6.1.2	List of speeds and formats available	2-11
6.2	Watchdog on Serie 4	2-12
6.3	Transmission speed, format and watchdog on Serie 4 Plus	2-13
7	Memory aid	2-14



1 Introduction

The printers in the Jaime 1000 Series 4 range are equipped with an asynchronous series, half duplex, interface, for connection to a V24 mode, "Voltage levels" or "20mA loop" transmission computer.

REMINDER "20mA loop" transmission affords good immunity against electric and electromagnetic interference. It is therefore particularly recommended for long distance connections or in a highly parasitic area.

ATTENTION A current loop adapter is required when "20 mA current loop" transmission is used on the S4 Plus printers.

The RS232C (or V24) standard describes the signals available during a dialog between a DTE (Data Terminal Equipment) and a DCE (Data Communication Equipment).

A maximum of 7 signals only are used for connection to an IMAJE printer of the Jaime 1000, whether for "voltage level" or "loop" transmission.

NOTE The Jaime 1000 printers should be considered as DTE.

ATTENTION Do not use the keyboard to make any changes to the printer during a V24 dialogue (risk of conflicts). You are also recommended to leave the S4 Plus printers in the "MAIN MENU" during a V24 dialogue.

2 Description of the signals used



2.1 Reference (GND)

Computer and printer earth in common.

2.2 DSR (Data Set Ready) in voltage levels transmission or DSR+ and DSR- in loop transmission.

A printer input. This signal activates the V24 mode.

A symbol appears on the screen when the DSR signal is active

 on S4 or  on S4 Plus.

2.3 DTR (Data Terminal Ready) in voltage levels transmission

A printer output. The signal is active as soon as the printer is ready to dialog.

2.4 RTS (Request To Send)

A printer output. The signal is active at every character sequence sent by the printer.

2.5 CTS (Clear To Send)



A printer input. The signal instructs the printer to send.

2.6 TXD (Transmit Data) in voltage levels transmission or TTY OUT+ and TTY OUT- in loop transmission.

A printer output. Data transmission.

2.7 RXD (Receive Data) in voltage levels transmission or TTY IN+ and TTY IN- in loop transmission.

A printer input. Data reception.




3 Electrical specifications



These are of V24, RS232C.

The input verification signals (DSR, CTS, RXD) are active when their voltage level is between + 3 V and + 12 V and inactive between - 3 V and - 12 V.

The output verification (DTR, RTS, TXD) are active at a voltage of 9 V and inactive at a voltage of - 9 V.



4 Timing diagram



5 Material configuration

5.1 Presentation of the terminal block of the Industrial Interface


To have access to the Industrial Interface card, unscrew the two fixing screws of its compartment housing at the rear of the printer.

Pass the connecting cable through one of the grommets and fix the wires to the corresponding terminals (see Figure 1).

NOTE The connecting cable shield used should be connected to the periphery of the metallic stuffing box of the printer and the same type of connection should be made on the computer.

Figure 1: Wiring of the V24 connection on B1 terminal block

1	TTYOUT-	Photocoupler output	20 mA current loop Factory set
2	TTYOUT+		
3	TTYIN-	Photocoupler input	20 mA current loop Factory set
4	TTYIN+		
5	-TXDOT	Transmit data	RS232C link
6	RTSOUT	Request to send	
7	DTROUT	Data Terminal ready	
8	-RXDIN	Receive data	
9	CTSIN	Clear to send	
10	DSRIN	Data send ready	
11	DSR-	Photocoupler DSR input	0V
12	DSR+		
13	GND		
14	SPROG 2		
15	COMSPROG		
16	SPROG 1		
17	COMRAZC 1		
18	RAZC1		
19	COMRAZC2		
20	RAZC2		
21	RESET-		
22	RESET+		
23	-DSR422-		
24	-DSR422+		
25	RXD422-		
26	RXD422+		
27	RXC422-		
28	RXC422+		
29	VALID422-		
30	VALID422+		
31	-DTR422-		
32	-DTR422+		
33	TXD422-		
34	TXD422+		
35	TXC422-		
36	TXC422+		
37	GND		
38	+ 5 V		
39	+ 15 V		
40	- 15 V		



5.2 Configuration of the jumpers on the Industrial Interface board

The jumpers on the Industrial Interface board allow configuration of the serial connection.

- **RXD** allows selection of the transmission mode
 - Position 232: voltage levels transmission,
 - Position 20 mA: loop transmission.
- **SW1** used only in "loop" transmission
 - Position active: active transmission,
 - Position passive: passive transmission.
- **SW2** used only in "loop" transmission
 - Position active: active reception,
 - Position passive: passive reception.

NOTE If the computer is configured in active the printer must be configured in passive on the corresponding line, and vice versa.

- **CTS**
 - Position DSR: The printer will only transmit data if the computer gives instructions to send (DSR active) (CTS linked to DSR).
 - Position CTS: The printer will only transmit data if the computer activates the CTS.
 - Position GND: The printer can transmit continually (CTS linked to 0 V).
 - Position RTS: The printer can transmit continually (CTS linked to RTS).

Figure 1 : Location of jumpers on the Industrial Interface Card




Figure 1

5.3 Presentation of the different modes


- **Slave:**
In this mode the computer alone can initialize a dialog and instruct the printer to send.
- **Complete dialog:**
In this mode both the computer and printer can initialize a dialog.
There is a check of the printer transmission.

NOTE **The printer dialogue is not permitted until after the start-up phase. In general, control by the computer of the DTR signal from the printer ensures that the latter is ready to dialog.**


5.4 Suggested connection diagrams


5.4.1 Slave. Voltage transmission

WIRING DIAGRAM




LOCATION OF JUMPERS






5.4.2 Slave. Loop transmission

WIRING DIAGRAM



POSITION DES CAVALIERS




NOTE The time between the appearance of the DSR signal (on the printer) and the activation of the DTR may be as much as 100 ms. In slave mode it is therefore necessary to take the response time into account automatically and to allow for a minimum time of 100 ms (see timing diagram, page 2-4).

REMINDER The printer dialogue is not permitted until after the start-up phase.


NOTE The value of 20 mA is preset in the factory.



5.4.3 Complete dialogue. Transmission in voltage.

WIRING DIAGRAM



LOCATION OF JUMPERS





6 Software configuration

The transmission speed, format and value of the watchdog are programmable from the printer keyboard in:

- the SHIFT MENU function for S4 printer,
- the PRINTER PREPARATION MENU, Initialization, V24 Connection for S4 Plus printer.

6.1 Transmission speed and format on Serie 4

6.1.1 Programming

Press	Display	Remarks
		For access to programmable parameters
		To be able to adjust the transmission speed (speed flashes)
		To reduce or increase transmission speed
		To be able to modify the format (format flashes)
		To modify the format
		For validation

6.1.2 List of speeds and formats available

- Speed (in bauds):

600 - 1 200 - 2 400 - 3 600 - 4 800 - 7 200 - 9 600 - 14 400 - 19 200 - 38 400

- Formats:


8 bits no Par.1 St. (8 bits without parity 1 stop)

8 bits no Par.2 St. (8 bits without parity 2 stop)

8 bits even Parity (8 bits with pair parity)











NOTE	All the coded data on several bytes should be transmitted, the high-order byte first. All the bytes should be transmitted, the least significant bit first.
-------------	--

WARNING	In "current loop" transmission, the transmission speed is restricted to 19200 baud maximum.
----------------	--



6.2 Watchdog on Serie 4

The watchdog is a value in tens of milliseconds representing a certain time above which the printer abandons a command if it has not received a complete command sequence from the calculator.

Press	Displays	Remarks
		For access to programmable parameters.
		
		
		For access to watchdog value.
		
		To be able to modify the value (the value can be modified using the numeric keypad from 0001 to 9999).
		
		For validation.
		
		

6.3 Transmission speed, format and watchdog on Serie 4 Plus

Go into the PRINTER PREPARATION menu, Initialisation, V24 connection.

The following dialogue box appears on the screen:



Jaime 1000	PRINTER PREPARATION MENU										
Initialization	Parameters Options Access codes										
<table border="1"> <tr> <td>Speed (baud rate):</td> <td>38400</td> </tr> <tr> <td>Parity:</td> <td>NO</td> </tr> <tr> <td>Stop bit(s):</td> <td>1</td> </tr> <tr> <td>Watchdog (s):</td> <td>5</td> </tr> <tr> <td colspan="2">8 bit format</td> </tr> </table>		Speed (baud rate):	38400	Parity:	NO	Stop bit(s):	1	Watchdog (s):	5	8 bit format	
Speed (baud rate):	38400										
Parity:	NO										
Stop bit(s):	1										
Watchdog (s):	5										
8 bit format											
V24 Connection Parameters											
↑ ↓ to select. SPACE to capture. ENTER / ESC to quit											

You can select:

- the transmission speed in baud (4800, 9600, 19200 or 38400),
- the party (none, even or odd),
- the number of stop bits (1 or 2),
- the watchdog value in seconds (from 1 to 99).

WARNING • The 8 bit transmission format cannot be changed.


REMINDER A current loop adapter is required when "20 mA current loop" transmission is used on the S4 Plus printers.



7 Memory aid

Conversion binary, decimal, hexadecimal.

Decimal	Binary	Hexadecimal
0	0000	0
1	0001	1
2	0010	2
3	0011	3
4	0100	4
5	0101	5
6	0110	6
7	0111	7
8	1000	8
9	1001	9
10	1010	A
11	1011	B
12	1100	C
13	1101	D
14	1110	E
15	1111	F




A byte (8 bits) is a suite of two hexadecimal numbers.
 The "h" symbol signifies hexadecimal notation.
 The ASCII norm allows the association of an alphanumerical symbol with each byte.




GENERAL PRINCIPLE OF A V24 EXCHANGE (3 pages)

Contents

1	General principle of a V24 exchange	3-2
1.1	Identification (1 byte hexadecimal)	3-3
1.2	Length (2 bytes in hexadecimal)	3-3
1.3	Data	3-3
1.4	Control byte (Checksum)	3-3




General principle of a V24 exchange





1 General principle of a V24 exchange

- Data sending from the computer to the printer



- Data request from the computer to the printer





1.1 Identification (1 byte hexadecimal)

Specific for each command (see table following pages).

1.2 Length (2 bytes in hexadecimal)

The length is the number of bytes comprised between the length and the checksum byte.

1.3 Data

Zero byte in case of request from the calculator to the printer.
 1 byte precised the jet number in case of a request concerning a jet.
 n bytes following one byte precising the jet number in case of a sent concerning a jet.
 n bytes without precising the jet number in case of a sent concerning the printer in general.

1.4 Control byte (Checksum)

This represents an "OR" exclusive of all preceding bytes (identification, length and data bytes).



Table of the "exclusive OR" Boolean function used for the checksum

X	Y	Result
0	0	0
0	1	1
1	0	1
1	1	0

Example of checksum calculation for two bytes:

- Value: 15h in binary	00010101
- Value: 56 h in binary	01010110
Result	<u>01000011</u>


Or, in hexadecimal = 43 h




**LIST OF THE V24 COMMANDS
(4 pages)**

Contents

1	Sendings	4-2
2	Requests	4-3
3	List of the V24 commands	4-4



List of the V24 commands



1 Sendings

Title of the command	Ident.	Page
PRINTER		
Stop/Start up printer	30h	5-3
Sending of reset faults	3Ch	5-4
Sending of keyboard code	3Eh	5-4
Sending of the security code	3Fh	5-5
Enable/disable the keyboard with DSR active	0Fh	5-6
Sending the request for printing acknowledgement	41h	5-6
Sending of the printer initialisation	36h	5-10
Downloading files to the S4 Plus	50h	5-12
HEAD		
Sending of jet status/maintenance	31h	5-15
MESSAGE		
Sending a complete message (printer without library)	0Ch	5-16
Sending of message parameters (printer without library)	0Bh	5-17
Sending of a message content (printer without library)	0Ah	5-18
Sending of a complete message in library	1Ch	5-19
Sending of a message parameters in library	1Bh	5-20
Sending of a message content in library	1Ah	5-21
Sending a partial message	42h	5-22
Sending of the message number to be printed	40h	5-24
Sending the contents of variable fields	4Ah	5-25
VARIABLES		
Sending the parameters of a counter	38h	5-26
Resetting the counters	3Ah	5-27
Sending the shift code parameters	3Dh	5-28
Initialisation of autoclock	C8h	5-29
Sending a Multitop per head and postdate 2 per jet	4Fh	5-30

2 Requests

Title of the command	Ident.	Page
PRINTER		
Request for V24 dialog	05h	5-31
Request of keyboard code	45h	5-32
Request for printer's parameters	20h	5-33
Request for the state of the ink circuit electrovalves, viscosity level, and number of additives	35h	5-34
Request for printer's CRC Proms	37h	5-36
Request for printer's faults	3Bh	5-38
Status request for S4SI	4Dh	5-42
HEAD		
Request for the status jet	32h	5-44
Request for the jet and phase speed	33h	5-45
MESSAGE		
Request for the complete current message	43h	5-46
Command of printing	94h	5-48
VARIABLES		
Request for current counters	39h	5-49
Request for autoclock	D6h	5-50
Request for shift code parameters	4Ch	5-51

3 List of the V24 commands

Ident.	Title of the command	Page	§
05h	Request for V24 dialog	5-31	5.1
0Ah	Sending of a message content (printer without library)	5-18	3.3
0Bh	Sending of message parameters (printer without library)	5-17	3.2
0Ch	Sending of a complete message (printer without library)	5-16	3.1
0Fh	Enable/disable the keyboard with DSR active	5-6	1.5
1Ah	Sending of a message content in library	5-21	3.6
1Bh	Sending of message parameters in library	5-20	3.5
1Ch	Sending of a complete message in library	5-19	3.4
20h	Request for printer's parameters	5-33	5.3
30h	Stop/Start up printer	5-3	1.1
31h	Sending of jet status/maintenance	5-15	2.1
32h	Request for the jet status/maintenance	5-44	6.1
33h	Request for the jet and phase speed	5-45	6.2
35h	Request for the state of the ink circuit electrovalves, viscosity level and number of additives	5-34	5.4
36h	Sending of the printer initialisation	5-10	1.7
37h	Request for printer's CRC Proms	5-36	5.5
38h	Sending the parameters of a counter	5-26	4.1
39h	Request for current counters	5-49	8.1
3Ah	Resetting the counters	5-27	4.2
3Bh	Request for printer's faults	5-38	5.6
3Ch	Sending of reset faults	5-4	1.2
3Dh	Sending the shift code parameters	5-28	4.3
3Eh	Sending of keyboard code	5-4	1.3
3Fh	Sending of the security code	5-5	1.4
40h	Sending of the message number to be printed	5-24	3.8
41h	Sending the request for printing acknowledgement	5-6	1.6
42h	Sending a partial message	5-22	3.7
43h	Request for the complete current message	5-46	7.1
45h	Request of keyboard code	5-32	5.2
4Ah	Sending the contents of variable fields	5-25	3.9
4Ch	Request for shift code parameters	5-51	8.3
4Dh	Status request for S4SI	5-42	5.7
4Fh	Sending a Multitop per head and postdate 2 per jet	5-30	4.5
50h	Downloading files to the S4 Plus	5-12	1.8
94h	Command of printing	5-48	7.2
C8h	Initialisation of autoclock	5-29	4.4
D6h	Request for autoclock	5-50	8.2

Contents


1	Sendings concerning the printer	5-3
1.1	Stop/Start up printer	5-3
1.2	Sending of reset faults	5-4
1.3	Sending of keyboard code	5-4
1.4	Sending of the security code	5-5
1.5	Enable/disable the keyboard with DSR active	5-6
1.6	Sending the request for printing acknowledgement	5-6
1.7	Sending of the printer initialisation	5-10
1.8	Downloading files to the S4 Plus	5-12
2	Sending concerning the print heads	5-15
	Sending of jet status/maintenance	5-15
3	Sendings concerning messages	5-16
3.1	Sending a complete message (printer without library)	5-16
3.2	Sending of message parameters (printer without library)	5-17
3.3	Sending of a message content (printer without library)	5-18
3.4	Sending of a complete message in library	5-19
3.5	Sending of a message parameters in library	5-20
3.6	Sending of a message content in library	5-21
3.7	Sending a partial message	5-22
3.8	Sending of the message number to be printed	5-24
3.9	Sending the contents of variable fields	5-25
4	Sendings concerning the variable elements (counter, hour code, auto-dating)	5-26
4.1	Sending the parameters of a counter	5-26
4.2	Resetting the counters	5-27
4.3	Sending the hour code parameters	5-28
4.4	Initialisation of auto-dating	5-29
4-5	Sending a Multitop per head and postdate 2 per jet	5-30

PROTOCOL

5	Requests concerning the printer	5-31
5.1	Request for V24 dialog	5-31
5.2	Request of keyboard code	5-32
5.3	Request for printer's parameters	5-33
5.4	Request for the status of the ink circuit electrovalves, levels, measured viscosity, reference viscosity, number of times additive has been added	5-34
5.5	Request for printer's CRC Proms	5-36
5.6	Request for printer's faults	5-38
5.7	Status request for S4SI	5-42
6	Requests concerning the heads	5-44
6.1	Request for the status jet	5-44
6.2	Request for the jet and phase speed	5-45
7	Requests concerning the message	5-46
7.1	Request for the complete current message	5-46
7.2	Command of printing	5-48
8	Requests concerning the variable elements	5-49
8.1	Request for current counters	5-49
8.2	Request for autoclock	5-50
8.3	Request for shift code parameters	5-51
9	General message structures	5-52
9.1	General structure of a one-line message	5-52
9.2	General structure of a two-line message	5-52
9.3	General structure of a three-line message	5-52
9.4	General structure of a four-line message	5-52
10	Detail of the data bytes	5-53
10.1	Jet number: from 1 to 4 (1 byte in hexadecimal)	5-53
10.2	General parameters of a message (11 bytes)	5-53
10.3	Parameters of variable elements	5-54
10.4	Delimiter of beginning of line: (0Ah)	5-54
10.5	Block	5-55
10.6	Logo block/symbol	5-64
10.7	Delimiter of end of message	5-64

1 Sendings concerning the printer

1.1 Stop/Start up printer




When the printer sends ACK, the jet is immediately stopped. The printer halts after 2 minutes.

WARNING

This command can only be used if the + 15 V power supply voltages are present when the printer is in standby mode (depends on the power supply model) and if DSR is active.


The printer will start up when the DSR signal appears.



1.2 Sending of reset faults

CALCULATOR


PRINTER




1.3 Sending of keyboard code

CALCULATOR

PRINTER



The locking code is a sequence of 3 ASCII characters (alphanumeric) comprised between 20h and 60h inclusive.
 To delete the locking code, send the coded sequence:
 30h/30h/30h for S4 and
 20h/20h/20h for S4 Plus.




1.4 Sending of the security code

This code protects the V24 messages. It can be initialised, therefore modified but not visualised. The calculator should recognise the preceding code in order to send other sequences of instructions.

CALCULATOR

PRINTER




The security code is a sequence of 3 ASCII characters (alphanumerical) comprised between 20h and 60h inclusive.


Transmission of NACK, SP corresponds to an incorrect security code.

NOTE The security code, if it was transmitted to the printer at the end of the previous utilisation, must be sent in the first sequence of each exchange.

REMINDER After a reset of the memory of the CPU board, the printer automatically sets the security code to "TWO".




1.5 Enable/disable the keyboard with DSR active




REMINDER Do not use the keyboard to make any changes to the printer during a V24 dialogue (risk of conflicts). You are also recommended to leave the S4 Plus printers in the "MAIN MENU" during a V24 dialogue.

1.6 Sending the request for printing acknowledgement



WARNING The print acknowledgement request should be sent to all the jets of a head.




Detail of the data bytes


- Detail of the "Jet number" byte

Printer	Head	Jet	Jet number
1.1	1	1	01h
1.2	1	1	01h
		2	02h
2.1	1	1	01h
	2	3	03h
2.2	1	1	01h
		2	02h
	2	3	03h
		4	04h
1.4	1	1	01h
		2	02h
		3	03h
		4	04h


- Detail of the "Printing acknowledgement" byte.



COMMENT Only one of these operating modes can be active at any one time.



1.6.1 Print acknowledgement



• **Detail of the print acknowledgement**

Head 1	Head 2	
E5h	E6h	After each object
E9h	EAh	After each batch
F1h	F2h	After each final counter value
E1h	E2h	On reception of DTOP if printing is impossible (fault or jet in start-up or shutdown phase)

1.6.2 Print acknowledgement with Status after each object




xxh	Print acknowledgement after each object	Data
xxh	General faults	
xxh xxh	Motor speed	
xxh	Pressure	
xxh	Viscosity	
xxh	Jet 1 speed	
xxh	Jet 2 speed	
xxh	Jet 3 speed	
xxh	Jet 4 speed	


Detailed description of data

• **Detail of the print acknowledgement**

Head 1	Head 2	
E5h	E6h	After each object
E1h	E2h	On reception of DTOP if printing is impossible (fault or jet in start-up or shutdown phase)



• **Detail of the "General faults" byte:**



1 = fault
0 = no fault

• **Detail of the "Motor speed" byte:**

The printer sends two hexadecimal bytes, representing the motor speed in decimal.

Calculation of the motor speed in rpm:
$$\frac{300\ 000}{\text{Motor speed in decimal}}$$

• **Detail of the "Pressure" byte:**

The printer sends one hexadecimal byte, representing the pressure in decimal.

Calculation of the pressure in millibars: pressure in decimal x 19.6 for heads M/G.
: pressure in decimal x 39.2 for head P.


• **Detail of the "Viscosity" byte:**

The printer sends one hexadecimal byte, representing the viscometer filling time in seconds.

• **Detail of the "Jet speed" bytes:**

The printer sends one hexadecimal digit, representing the jet speed in decimal.

Calculation of the jet speed in m/second:
$$\frac{\text{Jet speed in decimal}}{10}$$




1.7 Sending of the printer initialisation

ATTENTION The bytes marked with a * are ignored by the S4 Plus printers.

CALCULATOR

PRINTER



Detail of the data bytes

- **Language:**
* Byte ignored by S4 Plus printer.


00h	FRENCH	06h	NORWEGIAN
01h	ENGLISH	07h	SWEDISH
02h	GERMAN	08h	DANISH
03h	ITALIAN	09h	PORTUGUESE
04h	SPANISH	0Ah	JAPANESE
05h	DUTCH		

- **Watchdog V24:**
Time in tens of milliseconds, from 1 to 9999, in hexadecimal coding on 2 bytes.
* Bytes ignored by S4 Plus printer.

06h	ACK
-----	-----


or

15h	NACK
-----	------



- Cover/recup. fault byte:


State 0 = Fault active
 State 1 = Fault inactive



- Head type:

00h : 1 head single jet	03h : 2 heads twinjet
01h : 2 heads single jet	04h : 1 head four jets
02h : 1 head twinjet	

- Deferred stopping time:
 Time in minutes in hexadecimal coding on 2 bytes.
- Run/Stop autoclock:
 00h = Run FFh = Stop
- Machine operating time:
 Printer operating time expressed in hours and hexadecimal coded on 2 bytes.
** Bytes ignored by S4 Plus printer.*
- Number of print operations in multitop mode:
 Number of messages printed following an object TOP hexadecimally coded in two bytes
 If this value is equal to 0001h (default value), it is possible to parameterise a multitop operation for each printing head using the command 4Fh.
 If a different value is entered, the multitop operation applies to all the jets of all the heads.
 In this case, the Multitop command in 4Fh is inoperative.
- Number of library messages:
 Number of possible library messages, encoded in hexadecimal in one byte.
** Byte ignored by S4 Plus printer.*
- Jet "n" alignment:
 Number of delay frames which can be allocated to a jet relative to another in order to line up their respective printing.
 This number is encoded in hexadecimal in one byte.



1.8 Downloading files to the S4 Plus

It is possible to download DOS files to the S4 Plus printers.

- **for editing** - load the files MASTER, IMAJE.INI, S4P.BDG, *.GCG
- **for languages** - load the files *.RC, *.IDX

The downloaded files are copied to the root of drive **D:** (backed-up RAM).
The transfer format is as follows:

CALCULATOR


PRINTER



Identification		50h
Length		xxh xxh
Data	First block	00h
	Name of file (DOS)	---
Control byte		xxh



06h	ACK
or	
15h	NACK



Identification		50h
Length		xxh xxh
Data	Blocks 1 to (N-1)	01h
	File data (x bytes)	---
Control byte		xxh



06h	ACK
or	
15h	NACK

CALCULATOR

PRINTER

Identification		50h
Length		xxh, xxh
Data	Final block N	80h
	File data (x bytes)	---
Control byte		xxh




06h	ACK
or	
15h	NACK

Detail of the data bytes:

- "Name of file" bytes:
Maximum of 8 characters (DOS format)
- "Length" bytes:
The calculator sends 2 bytes in hex. format representing the length of the data (block number + file data).
Maximum length of file data = 1KB (1024 bytes).
- "Block number" bytes:
Transmissions must always be performed in the following order:
00h = transmission of the DOS file name in the file data (first block).
01h = transmission of blocks 1 to (N-1) of file data.
80h = transmission of final block (N) of file data.

ATTENTION

If the file already exists in the printer it will be overwritten when the first block containing the same file name is received. Downloaded files are not recognised until the printer is restarted.




Page intentionally left blank.

2 Sending concerning the print heads

Sending of jet status/maintenance

CALCULATOR

PRINTER



Detail of the data bytes :



- Number of the jet:

To command the jet(s) of head 1, send the following hexadecimal value: 01h

To command the jet(s) of head 2, send the following hexadecimal value: 03h

- State of the jet:

0	To stop the jet	00h
1	To start the jet	01h
2	To refresh the jet	02h
3	To stabilize the jet	03h
4	To introduce a solvent	04h
5	To unblock a nozzle	05h
6	To adjust the jet the gutter	06h




3 Sendings concerning messages


3.1 Sending a complete message (printer without library)

CALCULATOR


PRINTER




Detail of the data bytes




3.2 Sending of message parameters (printer without library)



Detail of the data bytes







3.3 Sending of a message content (printer without library)

CALCULATOR

PRINTER




Detail of the data bytes




3.4 Sending of a complete message in library


CALCULATOR

PRINTER




Detail of the data bytes






3.5 Sending of a message parameters in library




Detail of the data bytes




3.6 Sending of a message content in library


CALCULATOR

PRINTER



Detail of the data bytes






3.7 Sending a partial message


This command makes it possible to modify current messages, that is to say those selected for printing.

CALCULATOR

PRINTER



Detail of the data bytes




See following example.

- Sent of a complete message on the jet 1 (printer without library)




The printing is: IMAJE

- Modification of the message by **sending a partial message**




The printing is: IMITE




3.8 Sending of the message number to be printed

CALCULATOR


PRINTER



Detail of the data bytes



3.9 Sending the contents of variable fields



• **Detail of the "contents of variable fields"**

This field contains a string of characters in the exact order of the variable fields in the base message. The number of characters sent must be exactly equal to the number of spaces reserved in the base message. A bar code can be contained in a variable field.


NOTE:

In the base message, the variable fields are contained between two 12h delimiters.

E.g.:

Base message on jet 1:

WEIGHT: 12h xxx 12h Grams - PRICE: 12h xxxxx 12h Frs - 12h xxxx 12h Euros




Sending of variable fields:

4Ah 00h0Dh 01h 32517.752.69 xxh


Ident. Length N° jet 12 charac. Control ASCII

Print message:

WEIGHT: 325 Grams - PRICE: 17.75 Frs - 2.69 Euros



Protocol



4 Sendings concerning the variable elements (counter, hour code, autoclock)

4.1 Sending the parameters of a counter

With this command it is possible to modify the parameters of a current message counter: that is to say, those selected for printing.

CALCULATOR

PRINTER




Identification		38h
Length		00h, 18h
Data	Jet number	xxh
	Counter parameters	
	- Initial value	9 ascii
	- Final value	9 ascii
	- Step counter	2 ascii
- Batch counter	3 xxh	
Control byte		xxh




06h	ACK
or	
15h	NACK

4.2 Resetting the counters




Detail of the data bytes

Jet number (1 byte)			
↑			
Printer	Head	Jet	Jet num.
1.1	1	1	01h
1.2	1	1	01h
		2	02h
2.1	1	1	01h
	2	3	03h
2.2	1	1	01h
		2	02h
	2	3	03h
		4	04h
1.4	1	1	01h
		2	02h
		3	03h
		4	04h



4.3 Sending the shift code parameters



Detail of the data bytes


Jet number 1 byte				Starting time 2 bytes		Interval 2 bytes		Type code 1 byte	
Printer	Head	Jet	Jet num.	From 00 hours 00 minutes to 23 hours 59 minutes coded in hexadecimal on 2 bytes		From 00 hours 01 minutes to 23 hours 59 minutes coded in hexadecimal on 2 bytes		00h = 2 figured data code FFh = alphabetical code (complete alphabet) 7Fh = alphabetical code (less O and I)	
1.1	1	1	01h						
1.2	1	1	01h						
		2	02h						
2.1	1	1	01h						
	2	3	03h						
2.2	1	1	01h						
		2	02h						
	2	3	03h						
		4	04h						
1.4	1	1	01h						
		2	02h						
		3	03h						
		4	04h						

4.4 Initialisation of autoclock

CALCULATOR

PRINTER


Identification		C8h
Length		00h, 07h
Data	Second (1 byte)	xxh
	Minute (1 byte)	xxh
	Hour (1 byte)	xxh
	Day (1 byte)	xxh
	Month (1 byte)	xxh
	Year (1 byte)	xxh
Mode 24 hours (1 byte)	20h	
Control byte		xxh



All the data bytes, except the 24h mode, are coded in BCD (Binary Coded Decimal). The units are represented by the least significant half-byte.

The minimum and maximum values of these bytes are in decimal:


- second from 00 to 59
- minute from 00 to 59
- hour from 00 to 23
- day from 00 to 31
- month from 00 to 12
- year from 00 to 99



4-5 Sending a Multitop per head and postdate 2 per jet

CALCULATOR

PRINTER



Details of the data

- "Multitop" bytes:

This is the number of a message to be printed per DTOP (default value = 1).
 The multitop value must be identical for all the jets on a head.

It must be specific to each head in the case of 2-head printers.
 The multitop value for head 1 must be entered at jet 1 (master jet).
 The multitop value for head 2 must be entered at jet 3 (master jet).

- "Postdate 2" bytes: (from 0 to 9999 days) or (from 0 to 1872 months), bit 14 to bit 0
 - unit in days = 0 in bit 15
 - unit in months = 1 in bit 15

S4 printers:

The second postdate can only be accessed via V24.

It can be different for each jet but is the same for all the messages assigned to any given jet.
 To obtain a different postdate 2 for another message, it is necessary to transmit the new postdate interval using the command **4Fh**.

S4 Plus printers:

The second postdate is accessible via the printer's operator interface.

It is included in the messages and can be different for each jet and each message.


ATTENTION

If the message is selected via the machine's parallel interface, operation remains identical to that described in the case of S4 printers.

5 Requests concerning the printer


5.1 Request for V24 dialog

This request is optional. It enables the user, however, to ensure that the printer is "ready" to dialog. It can therefore be sent prior to each exchange.



The answer from the printer is NACK:

- if the liaison is locked by the security code,
- if the menu is being modified from the keyboard.



5.2 Request of keyboard code

CALCULATOR

PRINTER



Identification	45h
Length	00h, 00h
Control byte	45h





06h	ACK
45h	Identification
00h, 03h	Length
between 20h and 60h	Code 1 (1 ASCII)
between 20h and 60h	Code 2 (1 ASCII)
between 20h and 60h	Code 3 (1 ASCII)
xxh	Control byte

or


15h	NACK
-----	------


5.3 Request for printer's parameters





5.4 Request for the status of the ink circuit electrovalves, levels, measured viscosity, reference viscosity, number of times additive has been added






Detail of the data bytes

- Byte of the ELV of the CE:

State 0 = Closed
State 1 = Open




NOTE


On S4SI and S4SI Plus, all these solenoid valves are used.
On the other printers in the Jaime 1000 range, only the Additive and Visco. solenoid valves are used.

- Levels byte:

State 0 = Level attained
State 1 = Level not attained





- Viscosity byte:
The value represents the filling time of the viscometer in seconds, in hexadecimal coding.
- Visco reference byte:
Visco reference time in seconds, in hexadecimal coding.
- Additives byte:
Number of additions in hexadecimal coding.




5.5 Request for printer's CRC Proms

CALCULATOR

PRINTER






Detail of the data bytes


- Byte "Cover/recup. fault":

State 0 = active fault
 State 1 = inactive fault



- Byte "Printer's working hours":
 Printer operation time is expressed in hours and coded in hexadecimal on 2 bytes.-

- Byte "Nozzle type IMP":




Nozzle G:	0	0	0
Nozzle M:	1	0	0
Nozzle P:	1	1	0

- Byte "Type of GT IMP":



↑
 State 0 = ROM
 State 1 = RAM

- Byte "Run/Stop horo.":
 00h = Run FFh = Stop




Detail of the data bytes

- Byte: message general parameters

State 0 = no fault

State 1 = fault




* The bit 7 is significant on S4SI and S4SI Plus only.


* The bit 6 is not significant on S4SI and S4SI Plus only.

- Byte: Hard fault (CPU)

State 0 = no fault

State 1 = fault






Protocol

• Byte: printer's faults


State 0 = no fault
State 1 = fault



* The bits 1, 2 and 3 are significant on S4SI and S4SI Plus only.


• Byte: Hard fault IMP jet

State 0 = no fault
State 1 = fault




- Byte: IMP jet fault

State 0 = no fault
 State 1 = fault




- Byte: Head fault

State 0 = no fault
 State 1 = fault




- Byte: phase (on S4SI and S4SI Plus only)
 -----> Nr of the phase at fault

- Byte: Sub-phase (on S4SI and S4SI Plus only)
 -----> Nr of the sub phase at fault



5.7 Status request for S4SI




Details of the data bytes

- "Subphase time" bytes:
Time expressed in tenths of a second in two bytes.

• Levels byte:

State 0 = Level attained


State 1 = Level not attained



• Byte of the ELV of the IC:

State 0 = closed


State 1 = open



• Byte of the AP and discharge electrovalves:

State 0 = closed

State 1 = open



• "Pressure" byte:



The printer sends one hexadecimal byte, representing the pressure in decimal.

Calculation of the pressure in millibars:

- pressure in decimal x 19.6 for heads M/G.
- pressure in decimal x 39.2 for head P.


• "End of phase" byte: (stand-by mode)

00h for active phase.
 FFh for end of phase.



6 Requests concerning the heads

6.1 Request for the status jet



Detail of the data bytes


- Byte "Jet number":

Printer	Head	Jet	Jet num.
1.1	1	1	01h
1.2	1	1	01h
		2	02h
2.1	1	1	01h
	2	3	03h
2.2	1	1	01h
		2	02h
	2	3	03h
		4	04h
1.4	1	1	01h
		2	02h
		3	03h
		4	04h

- Byte "Status jet":

00h = Jet halted
 01h = Jet in start-up phase
 02h = Jet in refreshment
 03h = Jet in stability check
 04h = Jet in solution introduction
 05h = Jet in nozzle unblocking
 06h = Setting
 07h = Jet running

6.2 Request for the jet and phase speed




Detail of the data bytes

- "Jet number" byte:


Printer	Head	Jet	Jet num.
1.1	1	1	01h
1.2	1	1	01h
		2	02h
2.1	1	1	01h
	2	3	03h
2.2	1	1	01h
		2	02h
	2	3	03h
		4	04h
1.4	1	1	01h
		2	02h
		3	03h
		4	04h

- "Jet speed" byte:
The jet speed is expressed in tenths of a metre per second, coded in hexadecimal on 1 byte.

- "Jet phase" byte:
8 bits that can each take value 0 or 1.




Protocol





7 Requests concerning the message

7.1 Request for the complete current message



Detail of the data bytes






7.2 Command of printing

This command orders printing to the head(s). The printer should be configured in manual auto or manual object.

CALCULATOR

PRINTER



The response ACK is delivered if printing is effectively commanded (no verification of the printing done is carried out).

The response NACK signifies:

- The printing mode is different of the object manual or the auto manual.
- The printing has not started.


NOTE In "object manual" mode a single printing is triggered by this command.
 In "auto manual" the first command triggers the printing, the message is repeated until a second command stops the printing.


8 Requests concerning the variable elements

8.1 Request for current counters


CALCULATOR

PRINTER





8.2 Request for autoclock



8.3 Request for shift code parameters


CALCULATOR



PRINTER

Identification	4Ch
Length	00h, 01h
Jet number	xxh
Control byte	xxh

4Ch	Identification	Data
00h 05h	Length	
xxh xxh	Start time	
xxh xxh	Interval	
xxh	Code type	
xxh	Control byte	

Detail of the data bytes





9 General message structures

9.1 General structure of a one-line message

General message parameters	(11 bytes)
Parameters for variable elements	(26 bytes)
0Ah: delimiter of start of line	(1 byte)
Line 1: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Dh: delimiter of end of message	(1 byte)

9.2 General structure of a two-line message

General message parameters	(11 bytes)
Parameters for variable elements	(26 bytes)
0Ah: delimiter of start of line 1	(1 byte)
Line 1: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 2	(1 byte)
Line 2: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Dh: delimiter of end of message	(1 byte)

9.3 General structure of a three-line message

General message parameters	(11 bytes)
Parameters for variable elements	(26 bytes)
0Ah: delimiter of start of line 1	(1 byte)
Line 1: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 2	(1 byte)
Line 2: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 3	(1 byte)
Line 3: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Dh: delimiter of end of message	(1 byte)

9.4 General structure of a four-line message

General message parameters	(11 bytes)
Parameters for variable elements	(26 bytes)
0Ah: delimiter of start of line 1	(1 byte)
Line 1: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 2	(1 byte)
Line 2: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 3	(1 byte)
Line 3: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Ah: delimiter of start of line 4	(1 byte)
Line 4: subdivided into blocks	(from 0 bytes if line blank to n bytes)
0Dh: delimiter of end of message	(1 byte)

10 Detail of the data bytes

10.1 Jet number: from 1 to 4 (1 byte in hexadecimal)


Printer	Head	Jet	Jet num.
1.1	1	1	01h
1.2	1	1	01h
		2	02h
2.1	1	1	01h
	2	3	03h
2.2	1	1	01h
		2	02h
	2	3	03h
		4	04h
1.4	1	1	01h
		2	02h
		3	03h
		4	04h

10.2 General parameters of a message (11 bytes)

Message sense	0 = normal / 1 = inverted	b7	1 byte
Horizontal sense of the characters	0 = normal / 1 = inverted	b6	
Vertical sense of the characters	0 = normal / 1 = inverted	b5	
Tachometer mode	0 = no / 1 = yes	b4	
Manual mode	0 = no / 1 = yes	b3	
Command mode	0 = object / 1 = repetitive	b2	
NU	0	b1	
Mode DIN	0 = no / 1 = yes	b0	
Printing speed in mm/s or tachometer division	(2 bytes binary)		2 bytes
Forward margin in mm	(2 bytes binary)		8 bytes
Return margin in mm	(2 bytes binary)		
Interval in mm	(2 bytes binary)		
Object top filter in μ sec	(2 bytes binary)		

Minimum and maximum values of the general parameters :

Printing speed	0001 to 9999 mm/s
Tachometer division	0001 to 9999
Forward margin	0001 to 9999 mm
Return margin	0001 to 9999 mm
Interval margin	0001 to 9999 mm
Filtering	0100 to 9999 μ sec



10.3 Parameters of variable elements


Printing of leading zeros	0 = no	/	1 = yes	b7] 1 byte	
Counter incrementing on	0 = object	/	1 = message	b6		
Reset of object top counter	0 = no	/	1 = yes	b5		
Increasing / decreasing	0 = inc	/	1 = dec	b4		
Number of figures printed 1 to 9 (4 bytes)				b3 to b0		
Initial value	(9 bytes ASCII)] 23 bytes		
Final value	(9 bytes ASCII)					
Step counter	(2 bytes ASCII)					
Lot counter	(3 bytes binary)					
Postdate	unit	0=day	/	1 = month	b15] 2 bytes
	interval	in days	or	in months	b14 to b0	

Maximum and minimum values of the variable elements: (in decimal)

Initial value	000000000 to 999999999
Final value	000000000 to 999999999
Increase step counter	01 to 99
Lot counter	000001 to 999999
Postdate interval	0000 to 9999 days or 0000 to 1872 months

10.4 Delimiter of beginning of line: (0Ah)

This delimiter is the same for all lines.



10.5 Block

Bolderization from 1 to 9 (1 byte hexa)	Symbol Generator (1 byte hexa)	TEXT
--	-----------------------------------	------


10.5.1 Bolderization

From 1 to 9 (1 byte hexadecimal).

10.5.2 Symbol Generator

- On S4:


The symbol generators accessible in the printer can be visualised on the display of the printer.




NOTE

The symbol generator numbers are different on line 1 and 2. Display each number on the corresponding line.
The symbol generator numbers 255 to 241 are reserved for logos.

Example:





• **On S4 Plus:**

The symbol generators are designated by a name. This name corresponds to a number which you can find in one of the tables below.

Table 1

Fonts name	No
ARA16139	065
ARA24139	099
CYR16109	068
CHE5_1	58
CHE7_1	60
DAMIER	254
DI24_036	027
DS24_036	028
GRE16117	071
GRE24117	077
HEB16BAM	74
HEB24BAM	78
IG11_135	040
IG11_136	140
IGG11135	041
IN16_135	018
J1000	255
NY16_135	008
OC11_088	098
OC11_135	031
OC16_061	034
OC16_095	033
OC16_136	032
OC16_ITF	146
OCG11136	042
OCNU_ITF	147
OCR09_P1	144
PARAL	253
SCI11119	075
SCI16119	062
SIN09110	079
SIN11118	054
SIN16119	056
SIN24058	057

COMMENTS **A maximum of 15 fonts can be downloaded to the printer interface.
A maximum of 10 fonts can be used simultaneously in a message.**






Table 2: Positions of the 5 and 7-point fonts in the printing area

Fonts name	Position	No
ARA07139	F	063
	G	064
CYR07109	F	066
	G	067
GRE07116	F	069
	G	070
HEB07BAM	F	72
	G	73
IN05_1	C	50
	D	51
IN05_2	C	201
	D	202
IN07_1	F	52
	G	53
IN07_134	F	013
	G	014
OC07_086	F	029
	G	030
SCI05084	C	58
	D	59
SCI07119	F	60
	G	61
SIN05116	C	083
	D	084
SIN5H116	A	166
	B	167
SIN07118	F	52
	G	53
SIN7H118	E	160





10.5.3 Detail of TEXT

ASCII characters and/or Counter and/or Autoclock and/or Bar code and/or Tabulation and/or variable fields

- ASCII Characters: keyboard keys
- Counter: 1Ch (1 byte hexa)
- Autoclock:

Delimiter 1Ah	1 or more elements from the autoclock	Delimiter 1Ah
------------------	--	------------------

Elements of the autoclock:

41h = second (00 to 59) 42h	(2 bytes ASCII)
43h = minutes (00 to 59) 44h	(2 bytes ASCII)
45h = hours (00 to 23) 46h	(2 bytes ASCII)
49h = day of the month (01 to 31) 4Ah	(2 bytes ASCII)
4Bh = day of the year (01 to 366) 4Ch 4Dh	(3 bytes ASCII)
4Eh = week of the year (01 to 53) 4Fh	(2 bytes ASCII)
50h = month of the year (01 to 12) 51h	(2 bytes ASCII)
52h = month of the year in letters 53h (JAN to DEC) 54h	(3 bytes ASCII)
55h = year (00 to 99) 56h	(2 bytes ASCII)
57h = postday of the month (01 to 31) 58h first postdate	(2 bytes ASCII)

59h	= postday of the year (001 to 366)	(3 bytes ASCII)
5Ah	first postdate	
5Bh		
5Ch	= postweek of the year (01 to 53)	(2 bytes ASCII)
5Dh	first postdate	
5Eh	= postmonth of the year (01 to 12)	(2 bytes ASCII)
5Fh	first postdate	
60h	= postmonth of the year in letters	(3 bytes ASCII)
61h	(JAN to DEC)	
62h	first postdate	
63h	= postyear (00 to 99)	(2 bytes ASCII)
64h	first postdate	
65h	= shift code in letter (A to Z)	(1 byte ASCII)
66h	= shift code in number (01 to 99)	(2 bytes ASCII)
67h		
68h	= shift code in letters (A to Z - I -O)	(1 byte ASCII)
69h	= day of the week in number (1 to 7)	(1 byte ASCII)
6Dh	= separator : (2 points)	(1 byte ASCII)
6Eh	= separator / (slash)	(1 byte ASCII)
6Fh	= separator . (point)	(1 byte ASCII)
70h	= separator <input type="checkbox"/> (space)	(1 byte ASCII)

ATTENTION The hex values of the separators above apply only between 2 autoclock delimiters.



Protocol


71h	= postday of the month (01 to 31)	(2 bytes ASCII)
72h	second postdate	
73h	= postday of the year (001 to 366)	(3 bytes ASCII)
74h	second postdate	
75h		
76h	= postweek of the year (01 to 53)	(2 bytes ASCII)
77h	second postdate	
78h	= postmonth of the year (01 to 12)	(2 bytes ASCII)
79h	second postdate	
7Ah	= postmonth of the year in letters	(3 bytes ASCII)
7Bh	(JAN to DEC)	
7Ch	second postdate	
7Dh	= postyear (00 to 99)	(2 bytes ASCII)
7Eh	second postdate	


NOTE All these elements are dissociated (ie: last digit of the year = 56h)

• Bar Code


Delimiter 1Fh	Parameters (3 bytes)	BAR CODE CHARACTERS	Delimiter 1Fh
------------------	-------------------------	---------------------	------------------

Detail of the parameters bytes:






Protocol




The following table specifies the type of raster as a function of the value of bit7.
The current raster is the full raster of the current generator.
The jet raster is the raster used to connect the jets

	BIT7 = 0	BIT7 = 1
CODE 39	Current raster	Jet raster
2/5 INTERLACED	Current raster	Jet raster
EAN13	Jet raster	Current raster
EAN8	Jet raster	Current raster
ITF14	Jet raster	Current raster
ITF6	Jet raster	Current raster
EAN128	Jet raster	Current raster
CODE128	Jet raster	Current raster
UPCA	Jet raster	Current raster
UPCE	Jet raster	Current raster



3rd byte:
Wide bar
Wide space



Ratio between narrow and wide elements:
A narrow element must be strictly smaller than a wide element.

WARNING For some bar codes, certain parameters are pre-defined (see printer manual).

Bar Code characters:
Maximum length of a bar code: 32 characters included the control byte.


NOTE Maximum 4 bar code per message.

- Tabulation:

Delimiter 1Eh	Number of empty raster (1 to 255) (1 byte hexa)	Delimiter 1Eh
------------------	--	------------------

- Variable fields:

Delimiter 12h	Non-significant ASCII characters (field size)	Delimiter 12h
------------------	--	------------------



10.6 Logo block/symbol

10.6.1 Logo on Serie 4

Bolderization from 1 to 9 (1 byte hexa)	Symbol Generator (1 byte hexa)	! (21h)
--	-----------------------------------	----------------

- Bolderization: from 1 to 9 on 1 byte hexadecimal.
- Symbol Generator: from 255 to 241 (logo 1 : 255, logo 2 : 254 ... logo 15 : 241).
The logo must be loaded into the printer to be printed.
- The key **!** (21h) calls as many times as need the logo.

10.6.2 Symbol on Serie 4 Plus

Bolderization from 1 to 9 (1 byte hexa)	Symbol Generator (1 byte hexa)	Symbol Number
--	-----------------------------------	---------------



- Bolderization: from 1 to 9 on 1 byte hexadecimal.
- Symbol generator: No. of font (from 201 to 255).
- No. of symbols in the font:
 - Symbol No. 1 = 20h
 - Symbol No. 2 = 21h
 - etc...

10.7 Delimiter of end of message

This delimiter 0Dh marks the end of message.

Contents


1	Examples of message programming	6-2
1.1	Transmission of a one-line message	6-2
1.2	Transmission of a two-line message	6-3
1.3	Transmission of a three-line message	6-4
1.4	Transmission of a four-line message	6-6
2	Commanding the printer by a programme in BASIC	6-9
2.1	Sending of a complete message of two lines (printer without library)	6-9
2.2	Request for jet 1 state	6-12
	Performance	
	Performance Series 4	6-13
	Performance Series 4 Plus	6-14
	Synoptic of a V24 exchange	
	General principle of a V24 exchange	6-15
	Sending of a complete message (printer without library)	6-16



1 Examples of message programming

1.1 Transmission of a one-line message

Without parameters, on jet 1, outside of library, with fonts 16 x 12, No. 56 and 5x6 No. 84.




Sequence to be programmed:

Identifier	0Ah	Transmission of message contents outside of lib.
Length	00h, 13h	19 bytes
Number of jet	01h	Jet no 1
Start of line delimiter	0Ah	Line 1
Bolderization	02h	Bolderization 2
Symbol generator	38h	SIN16119 (no 56)
Text	IMAGE	6 ASCII characters
		Block 1, line 1
Bolderization	01h	Bolderization 1
Symbol generator	54h	SIN05116 (no 84)
Text	FRANCE	6 ASCII characters
		Block 2, line 1
End delimiter	0Dh	End of message
Checksum	07h	Check byte

1.2 Transmission of a two-line message

Without parameters, on jet 1, outside of library, with fonts 16 x 12 No. 56, 5 x 6 No. 83 and 5x6 No. 84.




ATTENTION When a message contains two lines, the two lines must end at the same position in order to be printable in "reverse message" direction.

Calculation of the number of balancing rasters for line 2:

Block 2, line 1 = 17 characters x bolderization 1 x 6 rasters/character = 102
 Block 1, line 2 = 6 characters x bolderization 2 x 6 rasters/character = 72
 Balancing = Difference, i.e. 30 rasters


Sequence to be programmed:

Identifier	0Ah	Transmission of message contents outside of lib.	
Length	00h, 2Ah	42 bytes	
Number of jet	01h	Jet no 1	
Start of line delimiter	0Ah	Line 1	
Bolderization	02h	Bolderization 2] Block 1, line 1
Symbol generator	38h	SIN16119 (no 56)	
Text	IMAJE	6 ASCII characters	
Bolderization	01h	Bolderization 1] Block 2, line 1
Symbol generator	53h	SIN05116 (no 83)	
Text	BOURG ...	17 ASCII characters	
Start of line delimiter	0Ah	Line 2	
Bolderization	02h	Bolderization 2] Block 1, line 2
Symbol generator	54h	SIN05116 (no 84)	
Text	FRANCE	6 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	1Eh	30 rasters	
Tab delimiter	1Eh	End tab	
End delimiter	0Dh	End of message	
Checksum	3Ah	Check byte	



1.3 Transmission of a three-line message

Without parameters, on jet 1, outside of library, with fonts 16 x 12 No. 56, 5 x 6 No. 83, 5x6 No. 84 and 7x6 No. 160.



ATTENTION When a message contains more than two lines, all the lines must be of the same length, i.e. have the same number of rasters, in order to be printable in "reverse message" direction.

Calculation of the longest line (line 2):

Block 1, line 2 = 6 characters x bolderization 2 x 12 rasters/character = 144
 Block 2, line 2 = 17 characters x bolderization 1 x 6 rasters/character = 102
 Total line 2 = Block 1 + Block 2 = 246 rasters

Calculation of number of balancing rasters for line 1:


A DOVER ... COMPANY = 28 characters x bolderization 1 x 6 rasters/character = 168 rasters
 Number of balancing rasters = 246 - 168 = 78 rasters
 I.e.: 18 rasters in front of the text and 60 rasters after it.

Calculation of number of balancing rasters for line 3:

FRANCE = 6 characters x bolderization 2 x 6 rasters/character = 72 rasters
 Space in front of "FRANCE" = block 1 of line 2, i.e. 144 rasters.
 Number of rasters after "FRANCE" = 246 - (144 + 72) = 30 rasters


Sequence to be programmed:

Identifier	0Ah	Transmission of message contents outside of lib.	
Length	00h, 52h	82 bytes	
Number of jet	01h	Jet no 1	
Start of line delimiter	0Ah	Line 1	
Bolderization	01h	Bolderization 1	Block 1, line 1
Symbol generator	A0h	SIN7H118 (no 160)	
Tab delimiter	1Eh	Start tab	
Number of rasters	12h	18 rasters	
Tab delimiter	1Eh	End tab	
Text	A... COMPANY	28 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	3Ch	60 rasters	
Tab delimiter	1Eh	End tab	
Start of line delimiter	0Ah	Line 2	
Bolderization	02h	Bolderization 2	Block 1, line 2
Symbol generator	38h	SIN16119 (no 56)	
Text	IMAJE	6 ASCII characters	
Bolderization	01h	Bolderization 1	Block 2, line 2
Symbol generator	53h	SIN05116 (no 83)	
Text	BOURG ...	17 ASCII characters	
Start of line delimiter	0Ah	Line 3	
Bolderization	02h	Bolderization 2	Block 1, line 3
Symbol generator	54h	SIN05116 (no 84)	
Tab delimiter	1Eh	Start tab	
Number of rasters	90h	144 rasters	
Tab delimiter	1Eh	End tab	
Text	FRANCE	6 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	1Eh	30 rasters	
Tab delimiter	1Eh	End tab	
End delimiter	0Dh	End of message	
Checksum	3Bh	Check byte	



1.4 Transmission of a four-line message

Without parameters, on jet 1, outside of library, with fonts 16 x 12 No. 56, 5 x 6 No. 83, 5x6 No. 84, 7x6 No. 160, 5x6 No. 166 and 5x6 No. 167.



ATTENTION When a message contains more than two lines, all the lines must be of the same length, i.e. have the same number of rasters, in order to be printable in "reverse message" direction.

Example breakdown of message:

Line 1

Block 1: - Space	18 rasters
- Text: A DOVER TECHNOLOGIES COMPANY	168 rasters
- Space	72 rasters
Block 2: - Text: Tel: (33) 4.75.75.56.00	144 rasters
- Balancing	12 rasters
Total line 1	414 rasters

Line 2

Block 1: - Space	255 rasters*
- Space	3 rasters*
- Text: Fax: (33) 4.75.82.98.10	144 rasters
- Balancing	12 rasters
Total line 2	414 rasters

* Since the maximum number of rasters is 255, the space required here (258 rasters) has been divided into two.

Line 3


Block 1: - Text: IMAJE □	144 rasters
Block 2: - Text: BOURG LES VALENCE □□ Web ... com	270 rasters
Total line 3	414 rasters

Line 4

Block 1 : - Space	144 rasters
- Text: FRANCE	72 rasters
- Space	42 rasters
Block 2 : - Text: Iso : □	36 rasters
Block 3 : - Text : 9001	48 rasters
- Balancing	72 rasters
Total line 4	414 rasters

Sequence to be programmed:

Identifier	0Ah	Transmission of message contents outised of lib.	
Length	00h, C0h	192 bytes	
Number of jet	01h	Jet no 1	
Start of line delimiter	0Ah	Line 1	
Bolderization	01h	Bolderization 1	Block 1 line 1
Symbol generator	A0h	SIN7H118 (no 160)	
Tab delimiter	1Eh	Start tab	
Number of rasters	12h	18 rasters	
Tab delimiter	1Eh	End tab	
Text	A...COMPANY	28 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	48h	72 rasters	
Tab delimiter	1Eh	End tab	
Bolderization	01h	Bolderization 1	Block 2 line 1
Symbol generator	A6h	SIN5H116 (no 166)	
Text	Tel ...	24 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	0Ch	12 rasters	
Tab delimiter	1Eh	End tab	



Appendix

Start of line delimiter	0Ah	Line 2	
Bolderization	01h	Bolderization 1] Block 1 line 2
Symbol generator	A7h	SIN5H116 (no 167)	
Tab delimiter	1Eh	Start tab	
Number of rasters	FFh	255 rasters	
Tab delimiter	1Eh	End tab	
Tab delimiter	1Eh	Start tab	
Number of rasters	03h	3 rasters	
Tab delimiter	1Eh	End tab	
Text	Fax ...	24 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	0Ch	12 rasters	
Tab delimiter	1Eh	End tab	
Start of line delimiter	0Ah	Line 3	
Bolderization	02h	Bolderization 2] Block 1 line 3
Symbol generator	38h	SIN16119 (no 56)	
Text	IMAJE □	6 ASCII characters	
Bolderization	01h	Bolderization 1] Block 2 line 3
Symbol generator	53h	SIN05116 (no 83)	
Text	BOUR ... com	45 ASCII characters	
Start of line delimiter	0Ah	Line 4	
Bolderization	02h	Bolderization 2] Block 1 line 4
Symbol generator	54h	SIN05116 (no 84)	
Tab delimiter	1Eh	Start tab	
Number of rasters	90h	144 rasters	
Tab delimiter	1Eh	End tab	
Text	FRANCE	6 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	2Ah	42 rasters	
Tab delimiter	1Eh	End tab	
Bolderization	01h	Bolderization 1	
Symbol generator	54h	SIN05116 (no 84)	
Text	Iso □: □	6 ASCII characters	
Bolderization	02h	Bolderization 2] Block 3 line 4
Symbol generator	54h	SIN05116 (no 84)	
Text	9001	4 ASCII characters	
Tab delimiter	1Eh	Start tab	
Number of rasters	48h	72 rasters	
Tab delimiter	1Eh	End tab	
End delimiter	0Dh	End of message	
Checksum	A5h	Check byte	

2 Commanding the printer by a programme in BASIC

2.1 Sending of a complete message of two lines (printer without library)

The message to send is:


```

IMAJE
JAIME 1000 Serie 4

```

The parameters are:

- Line 1	IMAJE in bolderization 1
- Line 2	JAIME 1000 Serie 4 in bolderization 2
- Message sense	normal
- Vertical sense	normal
- Horizontal sense	normal
- Printing speed	100 mm/s without tacho
- Command mode	object
- Forward margin	10 mm
- Return margin	10 mm
- Interval	10 mm
- Top filter	500 μ s
- Counter	printing of leading zeros: yes
	incrementing: object
	reset of object top: no
	initial value: 123456789
	final value: 987654321
	step counter: 05
	lot counter: 5
- Postdate interval	0



Appendix

After opening the communication port the following character sequence is to be sent:

identifier

PRINT #0,CHR\$(&h0C)+_

length

CHR\$(&h00)+CHR\$(&h44)+_

jet number

CHR\$(&h01)+_

mode and sense (in binary)

CHR\$(&b00000000)+_

printing speed

CHR\$(&h00)+CHR\$(&h64)+_

forward margin 10

CHR\$(&h00)+CHR\$(&h0A)+_

return margin 10

CHR\$(&h00)+CHR\$(&h0A)+_

interval 10

CHR\$(&h00)+CHR\$(&h0A)+_

object top filter 500ns

CHR\$(&h01)+CHR\$(&hF4)+_

counter parameters (in binary)

CHR\$(&b10001001)+_

initial value

CHR\$(&h31)+CHR\$(&h32)+CHR\$(&h33)+_

CHR\$(&h34)+CHR\$(&h35)+CHR\$(&h36)+_

CHR\$(&h37)+CHR\$(&h38)+CHR\$(&h39)+_

final value

CHR\$(&h39)+CHR\$(&h38)+CHR\$(&h37)+_

CHR\$(&h36)+CHR\$(&h35)+CHR\$(&h34)+_

CHR\$(&h33)+CHR\$(&h32)+CHR\$(&h31)+_

step counter

CHR\$(&h30)+CHR\$(&h35)+_

lot counter

CHR\$(&h00)+CHR\$(&h00)+CHR\$(&h05)+_

postdate interval

CHR\$(&h00)+CHR\$(&h00)+_

beginning line 1
CHR\$(&h0A)+_

bolderization line 1
CHR\$(&h01)+_

symbol generators line1
CHR\$(&h34)+_

text line 1: IMAJE
CHR\$(&h49)+CHR\$(&h4D)+CHR\$(&h41)+CHR\$(&h4A)+CHR\$(&h45)+_

end of the line 1
CHR\$(&h0A)+_

bolderization line 2
CHR\$(&h02)+_


symbol generators line2
CHR\$(&h35)+_

text line 2: JAIME 1000 Serie 4
CHR\$(&h4A)+CHR\$(&h41)+CHR\$(&h49)+CHR\$(&h4D)+CHR\$(&h45)+_
CHR\$(&h20)+CHR\$(&h31)+CHR\$(&h30)+CHR\$(&h30)+CHR\$(&h30)+CHR\$(&h20)+_
CHR\$(&h53)+CHR\$(&h65)+CHR\$(&h72)+CHR\$(&h69)+CHR\$(&h65)+CHR\$(&h20)+CHR\$(&h34)+_

end of the text line 1 and line 2
CHR\$(&h0D)+_

control byte
CHR\$(&h03)

After sending this succession of characters it is necessary to process the ACK or NACK reply given by the printer.



2.2 Request for jet 1 state

After opening the communication port the following character sequence is to be sent:


`PRINT#0,CHR$(&h32)+CHR$(&h00)+CHR$(&h01)+CHR$(&h01)+CHR$(&h32)`

The printer replies as follows:

- On 5 bytes: ACK, Identifier, Length, Jet state, Check.
- On 1 byte: NACK.

REMINDER	The value of the 4th byte (jet state) represents the state of the jet.. 00h = jet stopped 01h = jet in start phase 02h = jet refreshing 03h = jet in stability check 04 h = jet in solvent input 05h = jet in nozzle clearing 06h = adjustment 07h = jet in operation It is advisable to process the reply correctly.
-----------------	---

Performance Series 4



T0 = $\frac{\text{Nbr of bytes transmitted} \times \text{Nbr of bits per byte transmitted (10 or 11)}}{\text{Transmission speed}}$ in seconds

T1 = $0.0001 \times \text{Nbr of bytes transmitted in seconds.}$

If the message is complete:

T2 = $(46 \times 0.0001) + (0.0001 \times \text{Nbr of bytes transmitted})$ in seconds

message parameters
The number of bytes transmitted between the PRT board and CPU can increase if the message contains attributes (expansion, large characters...).

If the message is not complete: (no parameters sent)

T2 = $0.0001 \times \text{Nbr of bytes transmitted in seconds.}$

T3 = $(0.0001 \times \text{Nbr of bytes transmitted})$ in seconds.

The number of bytes transmitted between the PRT board and CPU can increase if the message contains attributes (expansion, large characters...).

T4 = Delay: from 0.5 ms to 2 ms if the PRT board receives the hour at this moment.
Bar codes: up 9 ms if code 39 with 31 characters and the check byte are present.

Watchdog:


- Greater than T0+T1 if message transferred without parameters outside of lib.
- Greater than T0+T1+T2+T3 if complete message transferred outside of library or if message transferred in lib.

Sending of the printing acknowledgement:

- 0.5 ms if the V24 link is free.
- 10 ms if the V24 link is busy.

Transmission of next message:

- It is possible to transfer a new message as soon as the acknowledgement of receipt has been received by the calculator.
- It is not possible to transfer a message from the CPU board to the print board (T2) until after the previous message has been printed.



$$T0 = \frac{\text{Nbr of bytes transmitted} \times \text{Nbr of bits per byte transmitted (10 or 11)}}{\text{Transmission speed}}$$

$$T01 = \frac{\text{Nbr of bytes transmitted} \times 10}{38400}$$

$$T1 = 0.0001 \times \text{Nbr of bytes transmitted in seconds.}$$

If the message is complete:

$$T2 = (46 \times 0.0001) + (0.0001 \times \text{Nbr of bytes transmitted}) \text{ in seconds}$$

message parameters
The number of bytes transmitted between the PRT board and CPU can increase if the message contains attributes (expansion, large characters...).

If the message is not complete: (no parameters sent)

$$T2 = 0.0001 \times \text{Nbr of bytes transmitted in seconds.}$$

$$T3 = (0.0001 \times \text{Nbr of bytes transmitted}) \text{ in seconds.}$$

The number of bytes transmitted between the PRT board and CPU can increase if the message contains attributes (expansion, large characters...).

$$T4 = \text{Delay: from 0.5 ms to 2 ms if the PRT board receives the hour at this moment.}$$

Bar codes: up 9 ms if code 39 with 31 characters and the check byte are present.

Watchdog:

- Greater than T0.

Sending of the printing acknowledgement:

- 0.5 ms if the V24 link is free.
- 10 ms if the V24 link is busy.

Storage of message at S4 Plus interface:


- Storage starts after the ACK and lasts for at least 80 ms.

Transmission of next message:

- It is possible to transfer a new message when storage of the previous message is terminated.
- It is not possible to transfer a message from the CPU board to the print board (T2) until after the previous message has been printed.

• Data sending from the computer to the printer


CALCULATOR PRINTER



INITIALISATION OF TRANSFER: OPTIONAL


• Data request from the computer to the printer

CALCULATOR PRINTER





INITIALISATION OF TRANSFER: OPTIONAL

Identification (1 byte)	Length (2 octets)	Data (0 to n bytes)	Control (1 byte)
Specific for each See table pages 4-2 to 4-4	The length is the number of bytes comprised between the length and the checksum byte.	Zero byte in case of request from the calculator of the printer. 1 byte specifying the jet number in case of a request concerning a jet. n bytes without specifying the jet number in case of a sending concerning the printer in general. n bytes following one byte specifying the jet number in case of a sending concerning a jet.	Checksum. This represent an "OP" exclusive of all preceding bytes (identification, length and data bytes).




Print. Head	Jet	Jet n°
1.1	1	1 01h
1.2	1	1 01h
	2	2 02h
2.1	1	1 01h
	2	3 03h
	1	1 01h
	2	2 02h
	3	3 03h
	4	4 04h
1.4	1	1 01h
	2	2 02h
	3	3 03h
	4	4 04h



Contents

1	Introduction	7-2
2	Characteristics of the Parallel link	7-3
2-1	Signals transmitted by the Parallel link	7-3
2-2	Characteristics of transmitted levels	7-3
3	Connection diagram	7-4



1 Introduction

The Parallel interface allows rapid selection and printing of a message stored in the library.

The options "Message selection" and "Message library" are necessary for using this mode of operation.

2 Characteristics of the Parallel link

2-1 Signals transmitted by the Parallel link

8 data input signals (D0 to D7) which enable the selection of the number of the message to be printed.

1 input signal, called "DTOP", which enables the validation of the active message number in the memory and starting-up of printing.

1 output signal, called "BUSY", which indicates that printing has started.

NOTE: The input/output signals being photocoupled on the Industrial Interface card each require an electrical reference wire (see Chapter 3 of present Section).

2-2 Characteristics of transmitted levels

The active level (logic 1) is comprised between 9 and 24 volts D.C.

The inactive level (logic 0) is comprised between 0 and 2 volts D.C. (see Figure 1).

The current admissible on input is comprised between 9mA and 25mA.

The input frequency must not exceed 10 KHz.

Figure 1 : Authorised logic level

- 1 — Active level (logic 1)
- 2 — Anactive level (logic 0)






Figure 1



Parallel link - Presentation




3 Connection diagram

To have access to the Industrial Interface card, unscrew the two fixing screws of its compartment housing at the rear of the printer.

Pass the connecting cable through one of the grommets and fix the wires to the corresponding terminals.

B2/IMP1 and B3/IMP2 terminal block

1	GND	OVA	Analog 0V
2	+ 24 T	+ 24 VE	+ 24 V supply not insulated galvanization.
3	CTP	DTOP -	Terminals for connection of the object detection cell.
4	TP	DTOP +	
5	CVI	VALIMP -	Inhibition of the object detection signal.
6	VI	VALIMP +	
7	CTH	TACHY -	Terminals for connection of the tachometric generator.
8	TH	TACHY +	
9	TH +	TACHY +	Terminals for connection of a differential tacho generator.
10	TH -	TACHY -	
11	C BU	BUSY -	Output for printing start-up signal.
12	BU	BUSY +	
13	C D	DATA (-)	Commun DATA (-)
14	D0	DATA (+) 8 bits	Inputs for Parallel interface printing used in "Message selection".
15	D1		
16	D2		
17	D3		
18	D4		
19	D5		
20	D6		
21	D7		
22	+ 24 T	+ 24 VE	+ 24 V supply not insulated by galvanization.



The input/output of the Parallel interface are photocoupled.

According to the voltages applied to the inputs, it is necessary to adjust the value of the resistance R (Figure 1) to obtain the nominal input current I_F .

The emitted signal must be positive in relation with its earth.

Example :




Figure 1 : Diagram of a photocoupled input






Figure 1



Connection of a Parallel interface to a SIGEA head movement

Terminal block for
SIGEA head movement



Terminal block for
Industrial Interface card



PARALLEL LINK - SELECTION OF MESSAGES (11 pages)

Contents

1	Selection of a message from the library	8-2
1.1	Encoding of message number in BCD format	8-2
1.2	Encoding of message number in hexadecimal mode	8-3
1.3	Option: reversed message direction	8-3
2	Input signals diagram	8-4
3	Master jet, master message	8-6
4	General operation of the parallel interface	8-7
5	Restriction of the parallel interface operation	8-7
6	Usage according to printer configurations	8-8
6.1	Printer 1.1 (1 single-jet print head)	8-8
6.2	Printer 1.2 (1 twin-jet print head)	8-8
6.3	Printer 2.1 (2 single-jet heads)	8-9
6.4	Printer 2.2 (2 twin-jet heads)	8-9
6.5	Printer 1.4 (1 head with 4 jets)	8-10
7	Summary charts	8-11
7.1	General	8-11
7.2	Special case	8-11



1 Selection of a message from the library

The signals D0 to D7 (which represent one byte of 8 bits) indicate the number of the active message to be printed and its type of coding.

The number of addressable messages in the library is variable (from 1 to 79 in decimal format, from 1 to 4F in hexadecimal format). It depends on the value displayed in the "SHIFT MENU" function in the case of S4 or in the menu Production, Message, Library in the case of S4 plus.

Validation and printing of the new message are performed by sending the DTOP signal.

Possible types of encoding for the message number: there are 3 possibilities.

1.1 Encoding of message number in BCD format


The BCD mode (Binary Coded Decimal, base 10) uses 4 bits, whose value is comprised between 0 and 9 (from 0000 to 1001 in binary code).

The units in the message number are represented by the bits 0, 1, 2 and 3.


The tens in the message number (from 0 to 7) are represented by the bits 4, 5 and 6.

Bit 7 must **obligatorily** be positioned at 1.

Example: request of message number 29.



"1" = active level
"0" = inactive level




1.2 Encoding of message number in hexadecimal mode

The hexadecimal mode (base 16) is coded on 4 bits, whose value is comprised between 0 and F (0000 to 1111 in binary code).

Bits 0 to 6 used for the message number.

Bit 7 must **obligatorily** be positioned at 0.

Example: request for message number 29 (1D in hexadecimal).





"1" = active level
 "0" = inactive level

1.3 Option: reversed message direction

If the printer is equipped with the "reverse message direction" option, the message number must be encoded in hexadecimal format.


Bit 7 is used to reverse the direction of message printing.
 0 = normal direction / 1 = reverse message direction



2 Input signals diagram

- Selection of message 1: number 1
- Selection of message 2: number 2

The data bits 2 to 7 are at 0.





Parallel link - Selection of messages

The minimum time between the stable signals D0 to D7 and the DTOP is 200 μ s.

The DTOP signal may drop out as soon as the BUSY signal is active.

The minimum activation time of the BUSY signal after a DTOP is 500 μ s.

The BUSY signal remains active during the full printing time of the message. It becomes inactive again as soon as the printer is available for a new message.



3 Master jet, master message

As a general rule, the "master jet" is jet number 1 of a print head.

Master messages are associated with master jets and their numbers advance by 1 in 1, 2 in 2 or 4 in 4, according to the printer configurations.

In practice, when the message is composed on the printer keyboard the master messages are those for which one can access to "message parameters".

4 General operation of the parallel interface

To print a message from the library, it is necessary:

- To present the message number to printer on the Parallel Interface (D0-D7) of the head concerned.
- To activate the DTOP signal, which:
 - memorizes the message number,
 - activates the print start-up.

The BUSY signal is activated at the start of printing. It becomes inactive at the end of the printing cycle.

A printing cycle consists of:

- a print of the message,
- phase recognition.

When the Parallel Interface is used in AUTO mode, the BUSY operates as described above for each message printed.

It can therefore be used to alter the message itself in this start mode.



If the printer receives a DTOP without the external inputs being activated, the last selected message is to be printed.

If the printer receives an invalid message number the last selected message is to be printed. A message number should be from 1 to the end of the library. Any message beyond the size of the library is invalid.

5 Restriction of the parallel interface operation

The option "Non double printing" is not available with the option "Message selection".

The use of postdate 2 is incompatible with the use of a parallel interface option.



6 Usage according to printer configurations

6.1 Printer 1.1 (1 single-jet print head)

- **Branching:**

Head 1 -----> D0-1 to D7-1, Dtop 1, BUSY 1

- **Usage:**

All the messages are "masters" and can be allocated to the single jet.

CAUTION The message number must not exceed the size of the library.

6.2 Printer 1.2 (1 twin-jet print head)

- **Branching:**

Head 1 -----> D0-1 to D7-1, Dtop 1, BUSY 1

- **Usage:**


Only odd numbered messages are "masters".
The message number to be presented to the parallel Interface must be that of Jet 1.
Jet 2 automatically and necessarily assumes the following message number.

Example:
Jet 1, "master" message Nr n (odd)
Jet 2, message (n+1)

CAUTION (n+1) must not exceed the size of the library.

- **Library storage:**

Message 1	Jet 1
Message 2	Jet 2
Message 3	Jet 1
Message 4	Jet 2
Message 5	Jet 1
.	
.	
.	
Message 77	Jet 1
Message 78	Jet 2



6.3 Printer 2.1 (2 single-jet heads)

- **Branching:**

Head 1 -----> D0-1 to D7-1, Dtop 1, BUSY 1
 Head 2 -----> D0-2 to D7-2, Dtop 2, BUSY 2

- **Usage:**

All the messages are "masters" and can be used indifferently on both heads provided they have the same character generators.

Otherwise:

Message 1	head 1
Message 2	head 2
Message 3	head 1
Message 4	head 2
Message 5	head 1
.	
.	
.	
Message 79	head 1

6.4 Printer 2.2 (2 twin-jet heads)

- **Branching:**

Head 1 -----> D0-1 to D7-1, Dtop 1, BUSY 1
 Head 2 -----> D0-2 to D7-2, Dtop 2, BUSY 2

- **Usage:**

Only the odd numbered messages are masters. The message number to be presented on the parallel Interface must be that of Jet 1 of the corresponding print head. Jet 2 of the same head then automatically and necessarily assumes the following message number.

Example:

Jet 1, "master" message Nr n (odd)
 Jet 2, message (n+1)

CAUTION (n+1) must not exceed the size of the library.

- **Library storage:**

Message 1	head 1 jet 1 (master message)
Message 2	head 1 jet 2
Message 3	head 2 jet 1 (master message)
Message 4	head 2 jet 2
Message 5	head 1 jet 1 (master message)



6.5 Printer 1.4 (1 head with 4 jets)

- **Branching:**

D0-1 to D7-1, Dtop 1 and BUSY 1
D0-2 to D7-2, Dtop 2 should be branched parallel with D0-1 to D0-7 and Dtop 1.

- **Usage:**

The message number to be presented on the parallel Interface for the head is that of Jet 1 of the corresponding head.
Jet 2 automatically assumes the message number on the basis of that of jet 1.
Jet 3 automatically assumes the message number on the basis of that of jet 2.
Jet 4 automatically assumes the message number on the basis of that of jet 3.


Example:
Jet 1 message n (master message)
Jet 2 message n + 1
Jet 3 message n + 2
Jet 4 message n + 3

CAUTION (n + 3) must not exceed the size of the library.

BUSY 1 is activated if the 4 jets are printing.

- **Library storage:**

Message 1	jet 1 (master message)
Message 2	jet 2
Message 3	jet 3
Message 4	jet 4
Message 5	jet 1 (master message)
.	
.	
.	
Message 73	jet 1 (master message)
Message 74	jet 2
Message 75	jet 3
Message 76	jet 4



7 Summary charts

7.1 General

Messages are:

- created by the operator Interface (machine keyboard),
- selected by the parallel Interface.

	Printer	1.1	1.2	2.1		2.2		1.4
	Head	1	1	1	2	1	2	1
	Master jet	1	1	1	3	1	3	1
Master message	n	01 02 03...79	01 03 05...77	01 03 05...79	02 04 06...78	01 05 09...73	03 07 11...75	01 05 09...73
Automatically associated messages	n + 1		02 04 06...78			02 06 10...74	04 08 12...76	02 06 10...74
	n + 2							03 07 11...75
	n + 3							04 08 12...76

7.2 Special case

Message are:

- created by the series Interface (V 24 connection)
- selected by the parallel Interface

Printer	1.1	1.2	2.1		2.2		1.4
Master message	x	x	x	x	x	x	x
Value of x	$1 \leq x \leq 79$	$1 \leq x \leq 78$	$1 \leq x \leq 79$		$1 \leq x \leq 78$		$1 \leq x \leq 76$
Message Nr on jet 2		x + 1			x + 1	x + 1	x + 1
Message Nr on jet 3							x + 2
Message Nr on jet 4							x + 3